

CLEAR FOCUS PVSee™ Installation Instructions



Recommended tools:

- Soft-edged squeegee designed specifically for wet application
- Isopropyl alcohol (optional)
- Water or suitable application solution in a spray bottle
- Masking tape for creating 'hinges' and positioning graphic, if needed
- Utility knife
- Pin

PVSee is designed for wet application using water or an application fluid, which allows the graphic to be repositioned during installation. A wet application also helps to prevent air bubbles from getting trapped between the film and the mounting surface.

Temperature of glass must be moderate — between approx. 40° F (5° C) and 90° F (32° C).

Preparation of Installation Surface

1. Wash the glass or other installation surface with mild soap and water. Rinse well with water. Do not use ammonia, Windex® or other solvent-based glass cleaner to clean the surface.
2. Moisten a clean cloth with isopropyl alcohol and wipe the surface to remove any residue. Dry with a lint-free paper towel.

Graphic Installation

1. If the graphic is large, cut some strips of masking tape and have ready to attach to the top of the graphic to create a hinge.
2. Peel the upper edge of the liner away from the PVSee graphic and fold the liner back approximately 6-8 inches (depending on the size of the graphic). Tape the top of the graphic in place if needed.
3. Lightly spray the top section of the installation surface with water or application fluid.
4. Lower the graphic and position it in place.
5. Squeegee the graphic using short, overlapping strokes to remove any trapped air, water or application fluid.
6. Working from the top to the bottom, continue by peeling away more of the liner, spraying more water or application fluid in sections, and squeegeeing the film. Continue in this manner until the liner is completely removed and the graphic is in place.
7. Wipe away any remaining water or fluid and examine the graphic for any bubbles under the surface. If there are any bubbles, use a pin or utility knife to gently prick the bubble and press the area with your finger to release the trapped air, water or application fluid.
8. Remove the tape hinge from the graphic.

Questions? Call or email us with any product questions or for technical support.

CLEAR FOCUS Imaging, Inc. 60 Maxwell Court, Santa Rosa, CA 95401

Tel: 1-800-307-7990 ♦ 707-544-7990 ♦ Fax: 707-544-1886

Email: headoffice@clearfocus.com ♦ Web: www.clearfocus.com